



CDS 101/110a: Lecture 6-1 Transfer Functions



Douglas MacMynowski
1 November 2010

Goals:



- Motivate and define the input/output transfer function of a linear system
- Understand the relationships among frequency response (Bode plot), transfer function, and state-space model
- Introduce block diagram algebra for transfer functions of interconnected systems

Reading:

- Åström and Murray, *Feedback Systems*, Ch 8
- *Advanced*: Lewis, Chapters 3-4 or DFT, Chapter 2

Frequency Domain Modeling

Defn. The *frequency response* of a linear system is the relationship between the gain and phase of a sinusoidal input and the corresponding steady state (sinusoidal) output.



Bode plot (1940; Henrik Bode)

- Plot gain and phase vs input frequency
- Gain is plotting using log-log plot
- Phase is plotting with log-linear plot
- Can read off the system response to a sinusoid – in the lab or in simulations
- Linearity \Rightarrow can construct response to any input (via Fourier decomposition)
- Key idea: do all computations in terms of gain and phase (frequency domain)

Transfer Function and Frequency Response

Exponential response of a linear state space system (from convolution)

$$y = Ce^{At} \left(x(0) - (sI - A)^{-1}B \right) + \left(C(sI - A)^{-1}B + D \right) e^{st}$$

transient
steady state

Transfer function

- Steady state response is proportional to exponential input => look at input/output ratio
- $G(s) = C(sI - A)^{-1}B + D$ is the *transfer function* between input and output

Frequency response

$$u(t) = A \sin \omega t = \frac{A}{2i} (e^{i\omega t} - e^{-i\omega t})$$

$$y_{ss}(t) = \frac{A}{2i} (G(i\omega)e^{i\omega t} - G(-i\omega)e^{-i\omega t})$$

$$= A \cdot |G(i\omega)| \sin(\omega t + \arg G(i\omega))$$

gain
phase

Common transfer functions

| | |
|--|--|
| $\dot{y} = u$ | $\frac{1}{s}$ |
| $y = \dot{u}$ | s |
| $\dot{y} + ay = u$ | $\frac{1}{s+a}$ |
| $\ddot{y} = u$ | $\frac{1}{s^2}$ |
| $\ddot{y} + 2\zeta\omega_n\dot{y} + \omega_n^2y = u$ | $\frac{1}{s^2 + 2\zeta\omega_ns + \omega_n^2}$ |
| $y = k_p u + k_d \dot{u} + k_i \int u$ | $k_p + k_d s + \frac{k_i}{s}$ |
| $y(t) = u(t - \tau)$ | $e^{-\tau s}$ |

Poles and Zeros

$$\begin{aligned} \dot{x} &= Ax + Bu & H(s) &= \frac{n(s)}{d(s)} \\ y &= Cx + Du & d(s) &= \det(sI - A) \end{aligned}$$

- Roots of $d(s)$ are called *poles* of $H(s)$
- Roots of $n(s)$ are called *zeros* of $H(s)$

Poles of $H(s)$ determine the stability of the (closed loop) system


- Denominator of transfer function = characteristic polynomial of state space system
- Provides easy method for computing stability of systems
- Right half plane (RHP) poles ($\text{Re} > 0$) correspond to unstable systems

Zeros of $H(s)$ related to frequency ranges with limited transmission

- A pure imaginary zero at $s=j\omega_z$ blocks any output at that frequency ($G(j\omega_z) = 0$)
- Zeros provide limits on performance, especially RHP zeros (more on this later)




$$H(s) = k \frac{s^2 + b_1s + b_2}{s^4 + a_1s^3 + a_2s^2 + a_3s + a_4}$$

pzmap



Plotting Bode Plots


- Evaluate the transfer function on the imaginary axis
 - Aside: This is sufficient to characterize the transfer function, follows from analyticity
- At frequency ω , then $G(i\omega) = r^{i\theta}$



```

Some useful matlab commands:
sys=ss(A,B,C,D);
G=tf(sys);
G=ss2tf(A,B,C,D);
n=[0 0 1];d=[1 0.1 1],G=tf(n,d)
s=tf('s');G=1/(s^2+0.1*s+1);
bode(G)
    
```

Example: Coupled Masses



$$H_{q_1f}(s) = k \frac{0.04}{s^4 + 0.08s^3 + 0.8016s^2 + 0.032s + 0.12}$$

$$H_{q_2f}(s) = k \frac{0.2s^2 + 0.008s + 0.08}{s^4 + 0.08s^3 + 0.8016s^2 + 0.032s + 0.12}$$

Poles (H_{q_1f} and H_{q_2f})


- $-0.0200 \pm 0.7743j$
- $-0.0200 \pm 0.4468j$

Zeros (H_{q_2f})

- $-0.0200 \pm 0.6321j$


Interpretation

- Zeros in H_{q_2f} give low response at $\omega \simeq 0.6321$




Series Interconnections

Q: what happens when we connect two systems together *in series*?




A: Transfer functions *multiply*

- Gains multiply
- Phases add
- Generally: transfer functions well formulated for frequency domain interconnections



Feedback Interconnection



State space derivation

$$\begin{aligned} \dot{x} &= u = r - ay = -ax + r \\ y &= x \end{aligned}$$

Frequency response $r = A \sin(\omega t)$

$$y = \left| \frac{1}{\sqrt{a^2 + \omega^2}} \right| \sin\left(\omega t - \tan^{-1}\left(\frac{\omega}{a}\right)\right)$$



Transfer function derivation

$$\begin{aligned} y &= \frac{u}{s} = \frac{r - ay}{s} \\ y &= \frac{r}{s + a} = G(s)r \end{aligned}$$

Frequency response

$$y = |G(i\omega)| \sin(\omega t + \angle G(i\omega))$$

Example: mass spring system



Rewrite in terms of “block diagram”

- Represent integration using $1/s$
- Include spring and damping through feedback terms
- Determine the transfer function through algebraic manipulation
- Claim: resulting transfer function captures the frequency response


$$y = \frac{1}{m} \cdot \frac{1}{s} \cdot \frac{1}{s} (F - c\dot{q} - kq) = \frac{1}{ms^2} F - \frac{c}{ms} y - \frac{k}{ms^2} y$$

$$\left(1 + \frac{c}{ms} + \frac{k}{ms^2}\right) y = \frac{1}{ms^2} F$$

$$y = \frac{1}{ms^2 + cs + k} F$$

$$H(s) = \frac{1}{ms^2 + cs + k}$$

Control Analysis and Design Using Transfer Functions



Transfer functions provide a method for “block diagram algebra”


- Easy to compute transfer functions between various inputs and outputs
 - $H_{er}(s)$ is the transfer function between the reference and the error
 - $H_{ed}(s)$ is the transfer function between the disturbance and the error

Transfer functions provide a method for performance specification

- Since transfer functions provide frequency response directly, it is convenient to work in the “frequency domain”
 - $H_{er}(s)$ should be small in the frequency range 0 to 10 Hz (good tracking)

Block Diagram Algebra

Basic idea: treat transfer functions as multiplication, write down equations



$$\begin{aligned} y &= P(s)u \\ u &= d + C(s)e \\ e &= r - y \end{aligned}$$

Manipulate equations to compute desired signals

$$\begin{aligned} e &= r - y \\ &= r - P(s)u \\ &= r - P(s)(d + C(s)e) \end{aligned} \quad \begin{aligned} (1 + P(s)C(s))e &= r - P(s)d \\ e &= \underbrace{\frac{1}{1 + P(s)C(s)}}_{H_{er}} r - \underbrace{\frac{P(s)}{1 + P(s)C(s)}}_{H_{ed}} d \end{aligned}$$

Note: linearity gives superposition of terms

Algebra works because we are working in frequency domain

- Time domain (ODE) representations are not as easy to work with
- Formally, all of this works because of Laplace transforms

Block Diagram Algebra

| Type | Diagram | Transfer function |
|----------|---------|---|
| Series | | $H_{y_2 u_1} = H_{y_2 y_1} H_{y_1 u_1} = \frac{n_1 n_2}{d_1 d_2}$ |
| Parallel | | $H_{y_3 u_1} = H_{y_3 y_1} + H_{y_3 y_2} = \frac{n_1 d_2 + n_2 d_1}{d_1 d_2}$ |
| Feedback | | $H_{y_1 r} = \frac{H_{y_1 u_1}}{1 + H_{y_1 y_2}} = \frac{n_1 d_2}{n_1 n_2 + d_1 d_2}$ |

- These are the basic manipulations needed; some others are possible
- Formally, could work all of this out using the original ODEs (nothing *really* new)

MATLAB manipulation of transfer functions

Creating transfer functions

- `[num, den] = ss2tf(A, B, C, D)`
- `sys = tf(num, den)`
- `num, den = [1 a b] → s2 + as + b`

Interconnecting blocks


- `sys = series(sys1, sys2)`, parallel, feedback

Computing poles and zeros

- `pole(sys)`, `zero(sys)`
- `pzmap(sys)`

I/O response

- `step(sys)`, `bode(sys)`



Summary: Frequency Response & Transfer Functions

