



## CDS 101/110a: Lecture 9-1 PID Control



Douglas MacMynowski  
22 November 2010


### Goals:

- Show how to use “loop shaping” using PID (Proportional + Integral + Derivative) to achieve a performance specification

### Reading:

- Åström and Murray, *Feedback Systems*, Ch 10
- *Advanced*: Lewis, Chapters 12-13

## Overview of Loop Shaping




### Performance specification

- ▶ Steady state error
- Tracking error
- Bandwidth
- ▨ Relative stability

### Approach: “shape” loop transfer function using $C(s)$

- $P(s)$  + specifications given
- $L(s) = P(s) C(s)$ 
  - Use  $C(s)$  to choose desired shape for  $L(s)$
- Important: can't set gain and phase independently

## Overview: PID control



$$u = k_p e + k_i \int e dt + k_d \dot{e}$$

### Intuition

- Proportional term: provides inputs that correct for “current” errors
- Integral term: ensures steady state error goes to zero
- Derivative term: provides “anticipation” of upcoming changes

### A bit of history on “three term control”

- First appeared in 1922 paper by Minorsky: “Directional stability of automatically steered bodies” under the name “three term control”
- Also realized that “small deviations” (linearization) could be used to understand the (nonlinear) system dynamics under control

### Utility of PID

- PID control is most common feedback structure in engineering systems
- For many systems, only need PI or PD (special case)
- Many tools for tuning PID loops and designing gains

CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS






3

## Proportional Feedback

### Simplest controller choice: $u = k_p e$

- Effect: lifts gain with no change in phase
- Good for plants with low phase up to desired bandwidth
- Bode: shift gain up by factor of  $k_p$
- Step response: better steady state error, but with decreasing stability

$$k_p > 0 \text{ if } P(0) > 0$$



CDS 101/110, 22 Nov 10




D. MacMynowski, Caltech CDS

4

## Proportional + Integral Compensation

**Use to eliminate steady state error**

- Effect: lifts gain at low frequency
- Gives zero steady state error
- Bode: infinite SS gain + phase lag
- Step response: zero steady state error, with smaller settling time, but more overshoot




CDS 101/110, 22 Nov 10



D. MacMynowski, Caltech CDS

5

## Proportional + Integral + Derivative (PID)



$$\begin{aligned}
 C(s) &= k_p + k_i \frac{1}{s} + k_d s \\
 &= k \left( 1 + \frac{1}{T_i s} + T_d s \right) \\
 &= (k T_d) \frac{(s + \alpha_i)(s + \alpha_d)}{s}
 \end{aligned}$$



CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS

6



## Implementing Derivative Action

### Problems with derivatives

- High frequency noise amplified by derivative term
- Step inputs in reference can cause large inputs
- Shows up in Gang of Four...

### Solution: modified PID control

- Use high frequency rolloff in derivative term
  - first order filter will give finite gain at high frequency
  - use higher order filter if needed
- Don't feed reference signal through derivative block
  - Useful when reference has unwanted high frequency content
  - Better solution: reference shaping via two DOF design ( $F(s)$  block)
- Many other variations (see AM08 + refs)



CDS 101/110, 22 Nov 10


D. MacMynowski, Caltech CDS

7

## Example: Cruise Control using PID - Specification



$$P(s) = \frac{1/m}{s + b/m} \times \frac{r}{s + a}$$



### Performance Specification

- $\leq 1\%$  steady state error
  - Zero frequency gain  $> 100$
- $\leq 10\%$  tracking error up to 1 rad/sec
  - Gain  $> 10$  from 0-1 rad/sec
- $\geq 45^\circ$  phase margin
  - Gives good relative stability
  - Provides robustness to uncertainty

### Observations

- Purely proportional gain won't work: to get gain above desired level will not leave adequate phase margin
- Need to increase the phase from  $\sim 0.5$  to 2 rad/sec and increase gain as well

CDS 101/110, 22 Nov 10


D. MacMynowski, Caltech CDS

8

## Example: Cruise Control using PID - Design



$$P(s) = \frac{1/m}{s + b/m} \times \frac{r}{s + a}$$



### Approach

- Use integral gain to make steady state error small (zero, in fact)
- Use derivative action to increase phase lead in the cross over region
- Use proportional gain to give desired bandwidth

### Controller

- $T_i = 1/0.1$ ;  $T_d = 1/1$ ;  $k = 2000$

$$C(s) = 2000 \frac{s^2 + 1.1s + 0.1}{s}$$

$$= 2200 + \frac{200}{s} + 2000s$$

### Closed loop system

- Very high steady state gain
- Adequate tracking @ 1 rad/sec
- $\sim 80^\circ$  phase margin
- Verify with Nyquist + Gang of 4

CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS




9

## Example: Cruise Control using PID - Verification



$$P(s) = \frac{1/m}{s + b/m} \times \frac{r}{s + a}$$

$$C(s) = 2000 \frac{s^2 + 1.1s + 0.1}{s}$$



### Observations

- Very fast response (probably too aggressive)
- Back off on  $T_i$  to get something more reasonable

CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS

10

# PID Tuning

## Zeigler-Nichols step response method


- Design PID gains based on step response
- Measure maximum slope + intercept
- Works OK for many plants (but underdamped)
- Good way to get a first cut controller

## Ziegler-Nichols frequency response method

- Increase gain until system goes unstable
- Use critical gain and frequency as parameters

## Variations

- Modified formulas (see text) give better response
- Relay feedback: provides automated way to obtain critical gain, frequency



Type	$k_p$	$T_i$	$T_d$
P	$1/a$		
PI	$0.9/a$	$3\tau$	
PID	$1.2/a$	$2\tau$	$0.5\tau$

(a) Step response method

Type	$k_p$	$T_i$	$T_d$
P	$0.5k_c$		
PI	$0.4k_c$	$0.8T_c$	
PID	$0.6k_c$	$0.5T_c$	$0.125T_c$

(b) Frequency response method


$$k_p = \frac{0.15\tau + 0.35T}{K\tau} \left( \frac{0.9T}{K\tau} \right), \quad k_i = \frac{0.46\tau + 0.02T}{K\tau^2} \left( \frac{0.3T}{K\tau^2} \right),$$

$$k_p = 0.22k_c - \frac{0.07}{K} \left( 0.4k_c \right), \quad k_i = \frac{0.16k_c}{T_c} + \frac{0.62}{KT_c} \left( \frac{0.5k_c}{T_c} \right).$$

# Example: PID cruise control





$$P(s) = \frac{1/m}{s + b/m} \times \frac{r}{s + a}$$





## Ziegler-Nichols design for cruise controller

- Plot step response, extract  $\tau$  and  $a$ , compute gains



- Result: *sluggish*  $\Rightarrow$  increase loop gain + more phase margin (shift zero)

## Windup and Anti-Windup Compensation




### Problem


- Limited magnitude input (saturation)
- Integrator “winds up”  $\Rightarrow$  overshoot

### Solution

- Compare commanded input to actual
- Subtract off difference from integrator



(a) Windup



(b) Anti-windup

CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS


14

## Summary: Frequency Domain Design using PID

### Loop Shaping for Stability & Performance


- Steady state error, bandwidth, tracking

$$H_{ue}(s) = K_p + K_I \frac{1}{s} + K_D s$$



### Main ideas

- Performance specs give bounds on loop transfer function
- Use controller to shape response
- Gain/phase relationships constrain design approach
- Standard compensators: proportional, PI, PID



CDS 101/110, 22 Nov 10

D. MacMynowski, Caltech CDS

15